

Key points




- 1 Update to the latest version***
- 2 Attach the holder to a tripod***
- 3 Ideal Installation***
- 4 Floor conditions***
- 5 Brightness Adjustment***
- 6 Distance Adjustment***

Point 1 **Update to the latest version**






12:20 📶 🔋

[← Today](#)



Golfboy:Launch Monitor
Simulator,Putt,Swing Analysis

997 RATINGS	AGE	CHART	DEVELOPER
4.6 ★★★★★	4+ Years Old	#90 Sports	 Qconcept, Inc.


What's New [Version History](#)





Version 15.3 2d ago

[Bugs]






- Fixed a bug in unit display
- Improved screen layout on iPad mini

Preview



   iPhone, iPad, and Apple Watch Apps 

Golfboy is a golf ball trajectory measurement application.
It can be used by anyone as long as they have an [if more](#)

 Today  Games  Apps  Arcade  Search

Point 2 **Attach the holder to a tripod**



We plan to begin sales of the dedicated tripod around September to October 2024.

NG

The screw hole on the holder is different when attaching it to the tripod.



OK

Correct tripod assembly



Tripod installation image



Point 3 *Ideal Installation*

The tilt is corrected by the iPhone's gyroscope, so it does not affect the measurement.

8~12 (20~30 cm)

Inches



It is not necessary to keep it level. The gyroscope will correct it.

Point 4

(both indoors and outdoors)

Floor conditions

NG




OK



Point 5 **Brightness Adjustment**

**Please adjust the brightness according to your usage environment.
A fixed setting is recommended.**



Point 6

Distance Adjustment

There may be some discrepancies depending on the type of range balls and the conditions of their placement.

Please be sure to adjust the ball distance settings before use.

